

Product Specifications

FlashLink BLE Logger

Measurement Range	-22°F to 140°F (-30°C to 60°C)
Accuracy	+/-0.9°F from -22°F to 140°F
Temperature Resolution	0.1°F/°C
Data Capacity	60,000 data points
Logging Interval	5 minutes
Start mode	Manual
Transmission Range:	2 seconds interval/~100ft (30.5m) at sight
Shelf Life	2 year
Battery	3.0v lithium battery
Dimensions/Body	1.38in x 0.43in (35mm x 11mm)
Casing	ABS plastic
Waterproof Rating	IP65
Weight	0.64 oz (18 grams) with battery
LED	Green and Red
Certification	CE Mark, FCC
System Requirements	Requires BLE Gateway Model 40993 to read and save data to the cloud
Bluetooth Connection	Bluetooth 4.0/5.0
On-Line Tracing	Customized web portal

The image shows the FlashLink BLE Logger product packaging, which is a green and white cardboard sleeve. The top of the sleeve features the DeltaTrak logo and the product name "FlashLink BLE Logger". Below this, there are instructions in both English and Spanish for the shipper and receiver. The shipper instructions include filling out a shipping label, peeling away the barcode label, and pressing the START button. The receiver instructions include completing the documentation and inspecting the shipment. The packaging also features a "START" button and a barcode. A US quarter coin is placed next to the product for scale.

SHIPPER INSTRUCTIONS

- Fill out the white shipping label below the BLE logger.
- Remove peel away barcode label from BLE logger, apply to shipping document.
- Press and hold START button until green ACTIVE LED strips flashing, then release the button.
- After activation green LED will flash every 2 seconds for 30 seconds.
- Use adhesive strips on back of card to attach BLE logger to the last pallet next to the door on top edge of pallet or carton.

INSTRUCCIONES DEL EMBARCADOR

- Llene la etiqueta de envío blanca debajo del registrador BLE.
- Retire la etiqueta de código de barras despegable del registrador BLE, aplíquela al documento del envío.
- Mantenga presionado el botón de INICIO hasta que el LED verde ACTIVO deje de parpadear, luego suelte el botón.
- Después de la activación, el LED verde parpadeará cada 2 segundos durante 30 segundos.
- Utilice las tiras adhesivas del reverso de la tarjeta para fijar el registrador BLE al último pallet junto a la puerta en el borde superior del pallet o caja.

RECEIVER INSTRUCTIONS

- Complete incoming documentation and inspection of the shipment.
- Remove the green instruction card with the BLE logger and place into the designated recycling box.

INSTRUCCIONES DEL RECEPTOR

- Completar la documentación entrante e inspección del envío.
- Retire la tarjeta de instrucciones verde con el registrador bluetooth y colóquela en la caja de reciclaje designada.

MODEL 40980-01

FDA Compliance: R12A-D02-180

Model 40980-01

- Single-use BLE temperature data logger
- Tracks environmental conditions inside vehicles during shipment
- Wirelessly transmits data by Bluetooth to Gateway device
- Temperature and location data stored in cloud-based FlashTrak web portal



www.cool-direct.com | info@cool-direct.com